

The power end termination must be terminated inside a UL/CUL Listed outlet box. Please refer to the DPPK accessory manual, steps 9 - 13.

KIT CONTENT

TOOLS REQUIRED



Component approvals and performance are specifically tied to the use of De-Icerman specified parts. Do not substitute any parts.

ATTENTION:


- The maximum permissible steady state Current is 30A.
- The rated voltage is 240V.
- The maximum continuous exposure temperature is 85°C.
- Temperature at the point of connection to branch circuit conductors may exceed 60 °C.

Warning: All heating cables shall have metal screen for working with branch circuit ground-fault protection to minimize the danger of fire if the heating cable is damaged or improperly installed.

STEP

1


For heating cable without outer jacket, skip Step 1, and proceed to step 2.



- Slightly cut the outer jacket of the cable 5.5inch(140mm) from the top of cable.
- Remove the outer jacket from heating cable.

STEP


2



- Unbraid the braid with a screw driver or any tapered tool from the top of cable. Do not break the braiding wires.
- Disperse the braiding wires to two strands. Align and twist the two strands of braiding wires.

STEP

3



- Straighten and twist the two strands into one.
- Slightly cut the inner insulation of the cable 4inch(100mm) from the top of cable.
- Remove inner insulation from heating cable.


STEP

4



- Warning: Do not damage the bus wires**
- Shave the core material(Black) from the outside of each bus wire.

STEP
5



- Peel back bus wires from the core material, and remove the remaining core material.


STEP
6



- Insert two bus wires into a $\varnothing 3$ (3inch/75mm) black shrink tube individually.
- Heat the shrinkable tubes with heat source by moving continuously from side to side.

Warning: Do not overheat the shrink tube

STEP
7



- Slide $\varnothing 12$ (2inch/50mm) shrinkable tube onto the place as shown.
- Heat the shrinkable tube with heat source until the glue comes out from both ends.
- Pinch the tube between two wires and hold for at least 10 seconds with pliers.

 **DE-ICERMAN**

info@deicerman.com

www.deicerman.com

1-647-894-1347